SOLDER SIDE		PARTS SIDE
GND	1	GND
GND	2	GND
+5V	3	+5V
+5V	4	+5V
	5	
+12V	6	+12V
	7	
COUNTER B	8	COUNTER A
GND	9	GND
SPEAKER(−)	10	SPEAKER(+)
	11	
GREEN	12	RED
SYNC	13	BLUE
SERVICE SW	14	GND
	15	
COIN B	16	COIN A
2P START	17	1P START
2P UP	18	1P UP
2P DOWN	19	1P DOWN
2P LEFT	20	1P LEFT
2P RIGHT	21	1P RIGHT
2P ATTACK	22	1P ATTACK
2P JUMP	23	1P JUMP
	24	
	25	
	26	
GND	27	GND
GND	28	GND

DIP SW 1

	1	2	3	4	5	6	7	8
NUMBER OF PLAYER								
3	OFF	OFF						
4	ON	OFF						
5	OFF	ON						
2	ON	ON						
DEMO SOUND			OFF					
NO DEMO SOUND			ON					
COIN MODE 2								
Selector A								
1coin 1play					OFF	OFF		
2coin 1play					ON	OFF		
3coin 1play					OFF	ON		
5coin 1play					ON	ON		
Selector B								
1coin 2play							OFF	OFF
1coin 3play							ON	OFF
1coin 5play							OFF	ON
1coin 6play							ON	ON
COIN MODE 1								
1coin 1play					OFF	OFF	OFF	OFF
2coin 1play					ON	OFF	OFF	OFF
3coin 1play					OFF	ON	OFF	OFF
4coin 1play					ON	ON	OFF	OFF
5coin 1play					OFF	OFF	ON	OFF
6coin 1play					ON	OFF	ON	OFF
1coin 2play					OFF	ON	ON	OFF
1coin 3play					ON	ON	ON	OFF
1coin 4play					OFF	OFF	OFF	ON
1coin 5play					ON	OFF	OFF	ON
1coin 6play					OFF	ON	OFF	ON
2coin 3play					ON	ON	OFF	ON
3coin 2play					OFF	OFF	ON	ON
5coin 3play					ON	OFF	ON	ON
8coin 3play					OFF	ON	ON	ON
Free play					ON	ON	ON	ON

DIP SW 2

	1	2	3	4	5	6	7	8
SCREEN NOMAL	OFF							
SCREEM REVERSE	ON							
TABLE TYPE		OFF						
UPRIGHT TYPE		ON						
COIN MODE 1			OFF					
COIN MODE 2			ON					
DIFFICULTY								
nomal				OFF	OFF			
hard				ON	OFF			
very hard				OFF	ON			
easy				ON	ON			
STOP MODE No						OFF		
Yes						ON		
NO DEATH MODE No							OFF	
Yes							ON	
NOT TEST MODE								OFF
TEST MODE								ON