

# 青春スキャンダル / MY HERO


COIN/CREDIT OPTIONS SWITCH SETTING

OPTION		DIP SWITCH #A							
		1	2	3	4	5	6	7	8
1 COIN	1 CREDIT	OFF	OFF	OFF	OFF	OFF	OFF	OFF	OFF
1 COIN	2 CREDITS	OFF	OFF	OFF	OFF	ON	OFF	OFF	OFF
1 COIN	3 CREDITS	OFF	ON	OFF	OFF	OFF	ON	OFF	OFF
1 COIN	4 CREDITS	ON	ON	OFF	OFF	ON	ON	OFF	OFF
1 COIN	5 CREDITS	OFF	OFF	ON	OFF	OFF	OFF	ON	OFF
1 COIN	6 CREDITS	ON	OFF	ON	OFF	ON	OFF	ON	OFF
2 COINS	1 CREDIT	OFF	ON	ON	OFF	OFF	ON	ON	OFF
3 COINS	1 CREDIT	ON	ON	ON	OFF	ON	ON	ON	OFF
4 COINS	1 CREDIT	OFF	OFF	OFF	ON	OFF	OFF	OFF	ON
2 COINS	3 CREDITS	ON	OFF	OFF	ON	ON	OFF	OFF	ON
2 COINS	1 CREDIT								
4 COINS	2 CREDITS	OFF	ON	OFF	ON	OFF	ON	OFF	ON
5 COINS	3 CREDITS								
6 COINS	4 CREDITS								
2 COINS	1 CREDIT	ON	ON	OFF	ON	ON	ON	OFF	ON
4 COINS	2 CREDITS								
1 COIN	1 CREDIT								
2 COINS	2 CREDITS	OFF	OFF	ON	ON	OFF	OFF	ON	ON
3 COINS	3 CREDITS								
4 COINS	4 CREDITS								
5 COINS	6 CREDITS								
1 COIN	1 CREDIT								
2 COINS	2 CREDITS	ON	OFF	ON	ON	ON	OFF	ON	ON
3 COINS	3 CREDITS								
4 COINS	5 CREDITS								
1 COIN	1 CREDIT	OFF	ON	ON	ON	OFF	ON	ON	ON
2 COINS	3 CREDITS								
		COIN SWITCH #1				COIN SWITCH #2			

OPTION SWITCH SETTING

OPTION		DIP SWITCH #B							
		1	2	3	4	5	6	7	8
TABLE UPRIGHT		OFF							
ADVERTISE SOUND	OFF	ON							
	ON		OFF						
NUMBER OF PLAYERS	3 MEN			OFF	OFF				ON
	4 MEN			ON	OFF				
	5 MEN			OFF	ON				
	FREE			ON	ON				
SCORE OF ADDITIONAL PLAYER	30000					OFF	OFF		ON
	50000					ON	OFF		
	70000					OFF	ON		
	90000					ON	ON		
GAME DIFFICULTY	EASY							OFF	
	HARD							ON	


DIP SWITCH #B



BARE BD No.

- 171-5054-02
- 171-5054-03

44 PIN P=3.96mm



JOYSTICK CONTROL DIRECTIONS



SUPPLY VOLTAGES & CURRENT

VOLTAGE	CURRENT
DC5V	4.1A
DC12V	0.25 A

