


No. 19096-A Amplifier Assembly (Less Tubes)



| Part No. | Description |
|----------|---|
| 1 | 19002 Power Transformer |
| 2 | 16810 4 Prong Miniature Socket |
| 3 | 18411 Hum Control |
| 4 | PH-3191 6L6 Tube |
| 5 | 18634 6 Prong Miniature Socket |
| 6 | 18436 Standee Resistor |
| 7 | 18385 6 SN7 GTA Tube |
| 8 | 18412 Tube Shield |
| 9 | 18402 Input Socket |
| 10 | 11578 Painter Knob |
| 11 | PH-3523 3 Amp. Fuse |
| 12 | 19003 Output Transformer |
| 13 | 18414 6 Prong Socket |
| 14 | PH-3190 5U4 Tube |
| 15 | 16924 Input Capacitor <i>20mF/475v</i> |
| 16 | 18385 6 SN7 GTA Tube |
| 17 | 18401 Terminal Strip |
| 18 | 16926 Filter Capacitor <i>20-20-20mF/475v</i> |
| 19 | 18403 Slide Switch (SPDT) |
| 20 | 18606 Slide Switch (DPDT) |

(No. 19096-A Amplifier Assembly (Less Tubes)

| Part No. | Description |
|----------|----------------------------------|
| 1 | 19072 .002 MFD. 400 V. Condenser |
| 2 | 19076 15,000 ohm Resistor |
| 3 | 13320 1 Megohm Resistor |
| 4 | 18417 .01 MFD. 400 V. Condenser |
| 5 | 17788 .47 MFD. 200 V. Condenser |
| 6 | 19067 25 MFD. 15 V. Condenser |
| 7 | 19075 .1 MFD. 200 V. Condenser |
| 8 | 19075 .1 MFD. 200 V. Condenser |
| 9 | 19066 .05 MFD. 600 V. Condenser |
| 10 | 16925 Filter Resistor |
| 11 | 11555 Fuse Halder |
| 12 | 14121 5 Ohm 5 Watt Resistor |
| 13 | 19066 .05 MFD. 400 V. Condenser |
| 14 | 19028 50 MFD. 50 V. Condenser |
| 15 | 16222 6800 Ohm Resistor |
| 16 | 18403 Slide Switch (SPDT) |
| 17 | 18606 Slide Switch (DPDT) |
| 18 | 15403 27,000 Ohm Resistor |
| 19 | 18651 Tone Control |
| 20 | 13015 47,000 Ohm Resistor |
| 21 | 19074 .01 MFD. 200 V. Condenser |
| 22 | 19182 .033 MFD. 200 V. Condenser |
| 23 | 19067 25 MFD. 15 V. Condenser |
| 24 | 18651 Tone Control |
| 25 | 19084 Audio Reactore |

