


No. 19705-A Power Distribution Panel Assembly




Part No.	Description
1	17604 Control Circuit Transformer
2	19006 Miniature Outlet
3	17596 4 Prong Socket
4	19006 Miniature Outlet
5	PH-3722 4 Prong Socket
6	PH-3740 5 Prong Socket
7	19008 6 Prong Jones Socket
8	ST-4321 1.6 Amp. Fuse
9	ST-3090 3 Amp. Slo-Blo Fuse
10	19006 Miniature Outlet
11	PH-3523 3 Amp. Fuse
12	ST-3092 10 Amp. Fuse
13	19006 Miniature Socket

No. 19705-A Power Distribution Panel Assembly

Part No. Description

1	11555	Fuse Holder
2	17621	Power Rectifier
3	18859	Start Relay (D.C.)
4	18417	.01 MFD. 400 V. Condenser
5	15476	.002 MFD. 1200 V. Condenser



Additional Parts Listing

Part No.	Description	Part No.	Description
1	ST-3046 Type #44 Bulb	12	19726 10¢ and 3 for 25¢ Decal
2	ST-6028 Caster	13	19725 5¢ - 10¢ - 25¢ Decal
3	ST-7379 Cash Door Lock	14	19724 5¢ - 10¢ - 6 for 25¢ Decal
4	ST-7392 Rear Door Lock	15	18930 Cash Door Frame
5	ST-7394 Front Door Lock	16	18938 Cash Bag
6	12053 20 W. Fluorescent	17	19727 10¢ and 4 for 25¢ Decal
7	13362 Master Line Switch	18	19292 15" Hi-Fi Speaker
8	15159 Momentary Push Switch	19	19106-A Volume Control Assembly
9	17008 Needle Brush	20	19614-A Skid Front Casting Assem.(R.H.)
10	17804 Brush Wire	21	19615-A Skid Front Casting Assem.(L.H.)
11	17958 Leveling Bolt	22	19172-A Cash Door Assembly