

CENTIPEDE:

To stop the track ball from skipping, change whatever is in positions R-84, R-86, R-131, 133 to 6.8K OHM, only on A-F Revisions. Later boards have these resistors in place.

To stop intermittent no fire or intermittent no coin/credit, change R-115, R-117, R-119, and R-120 from 1K OHM to 470 OHM.