## RAM/ROM TEST FAILURE

If Self-Test falls to advance to Test No. 1, check the lighting of LEDs L1 thru L4 on the Processor PCB (located directly below this label)

## If L1 is ON

and L2 is ON — indicates a failure of RAM in location H6

or L3 is ON — Indicates a failure of RAM in location K6

or L4 is ON - Indicates a failure of RAM in location J6

## if L1 is OFF

and L2 is ON — indicates a failure of ROM in location K/L7

or L3 is ON — indicates a failure of ROM in location M7

or L4 is ON - indicates a failure of ROM in location J7

